


NEW!
more on
reverse

TV BRIDGE™ II Kits

Pre-Wired, Pre-Assembled Box Kits for Flat Screen TV Installations




Arlington's new non-metallic **TV Bridge™ II** box kits are the easiest, fastest way to install a flat screen TV. They include *two* boxes and the necessary connections needed to install the TV and additional components.

Installation is *faster* because we've done the advance assembly work for you! You'll get a fully assembled, recessed box, with pre-wired receptacle, device, flexible cord and cord grip.

All you need to do is cut two openings in the wall, near a power source. There's no need to cut into your framing members or run power from a panel box.

- Mounting wing screws hold the boxes secure against the wall
- Plugs and connections stay inside the recessed boxes so TV mounts flush against the wall
- No mess! – wires stay hidden behind the wall
- **TV Bridge™ II** kits in four styles...

Pre-wired TV Bridge™ II Kits in four styles...



- **TVB712BK** power/low voltage box (power side angled)
- **TVBRA2K** power/low voltage box
- **TVBRA1K** Single-gang power box
- **TVBRA3K** power/low voltage box at top, single gang at bottom



Arlington

1 Stauffer Industrial Park
Scranton, PA 18517
800/233.4717
Fax 570/562.0646
www.aifittings.com

Patent pending

TV BRIDGE™ II Series **NEW!**

Pre-wired, Ready-to-use Box Kits for Existing Walls

UPPER Box installation (TVB712BK shown)



- 1 Cut Top hole in wall for the TV.
Cut Lower hole directly below the top hole, close to an existing outlet.



- 2 Drop the pre-wired device box assembly and cable through the top hole, feeding it toward the bottom hole.



- 3 Place box in Top hole.
Feed low voltage cables for TV through opening in box.
Tighten mounting wing screws to secure box to wall.

(continue with Lower Box installation below)


To complete the installation:
Energize TV Bridge II by plugging into power source (existing outlet) or (optional) surge protector.




LOWER Box installation



- 1 Pull pre-wired device assembly through bottom hole.



- 2 Attach device box to trim plate with screws provided. Secure trim plate to wall with mounting wing screws. Install CED130 in 2-gang boxes. Pull cables.




- 3 Attach cover plate to trim plate with screws provided.



| Catalog Number | UPC/DEI/NAED Mfg. #018997 | Description TV BRIDGE™ II Kit | Unit/Std Pkg |
|----------------|---------------------------|--------------------------------------------------------------------------------------|--------------|
| TVBRA1K | 24180 | w/ single-gang boxes | 1 |
| TVBRA1KGC | 24182 | w/ single-gang boxes - w/ ground clips for Canada | 1 |
| TVBRA2K | 24181 | w/ 2-gang power/low voltage box | 1 |
| TVBRA2KGC | 24183 | w/ 2-gang power/low voltage box - w/ ground clips for Canada | 1 |
| TVBRA3K | 24195 | 2-gang power/low voltage upper box, single gang (lower) | 1 |
| TVBRA3KGC | 24196 | 2-gang power/low voltage upper box, single gang (lower) - w/ ground clips for Canada | 1 |
| TVB712BK | 12781 | w/ 2-gang power/low voltage box (power w/ angled opening) | 1 |
| TVB712BKGC | 12782 | w/ 2-gang power/low voltage box (power angled) - w/ ground clips for Canada | 1 |



1 Stauffer Industrial Park
Scranton, PA 18517
800/233.4717
Fax 570/562.0646
www.aifittings.com



Distributed by